

ワープロ用リボンカセット 適用機種一覧表

シャープ純正リボンカセット

リボン品番	メーカー	シャープ
TY156BKX (黒)		WD-A351, A521, A541, A550, A551, A560, A561, A570, A600, A610, A750, A751, A760, A761, A770, A780, A810, A850, A950 X300, X500, X600, X800, X870 C500, C530, C700, C900 Y300, Y330, Y340, Y380, Y390, Y550 SB30, SB55, SB60, SR3L, SR4L, SR5L, SR6L, SD50, RS95 J100, M300 WL-3000CJ PC-WD1A, WD1AD, WD1B, WD1BD, WD2A, WD2AD

タイプEWの適用機種については裏面をご覧ください。

共通リボンカセット/タイプW

リボン品番	メーカー	シャープ	NEC	富士通	東芝	カシオ	松下	三洋	日立	リコー
RW301ABK (黒)		WD-J150, J200, CP1, CP2, MA-10 リボン品番: RW301ABK	5H, 5HA, 5HD, 5HG, 5HL, 5HS, 5R, 5RC, 5RD, 5RG, 5RS, 5RX, 5S, 5SC, 5SH, 5SV, 5SX, 7H, 7HA, 7HD, 7HG, 7HR, 7R, 7RA, 7RD, 7RG, 7RM, 7RX, 7S, 7SD, 7SR, 7SV, 7SX, 7 (II F, II H), PWP-50H, 50HD, 50HG, 50HS, 50R, 50RC, 50RG, 50RS, 50RX, 70H, 70HG, 70HR, 70R, 70RA, 70RG, 70RX, PC-PR150T リボン品番: PWP-IR21, 31, 41, 61, EF-1602B, 1617BN, IR-W-B ※金, 銀は適用致しません	(30AD301, 30AD401, 30AD405,) 30AF III, 30AP101, 30AX, 30AX II, 30AX301, 30AX401, 30AX-CD, 30AX-W, 30EX, 30LG101, 30LS, 30LS201, 30LX, 30LX II, 30LX III, 30LX401, 30LX405, 30LX501, 30LX601, 30LX605, 30LX651, 30MS, 30MX, 30SX, 30SX II, 30SX301, 30SX401, 30SDX101, 70AF, 70F, 10, 11 (D/S), 12LX, F6163T1, F6143TN1, 40AP リボン品番: 0313110, 0313115, 0313410	JW-03, 05 (H/HG/W), 95HV, 95KV II, 98HD, 98V, 98W リボン品番: JW-Z300, R3067	CX-1, 3, 5, 10, 11, 20, HX-1, 3, 5, 6, 7, 8, 10, HW-3000 (Ai), 9000 (Ai), 9200 (Ai/F/G), 9300 (Ai/DF/V), 9400J, 9500 (Ai/V), 9800 (Ai/DF/GX/HR/JX/VX), 9800 (VX II/XL), 9850HR, 9900 (JX/RX/VX/VX II), 850DXN, 300A, 75VF, HV-200L, 250L, 260L, 270L, 280L, 290L, 700L, GX-40, 50 リボン品番: T-W-BK, IR-45BK, NR-40BK ※金, 銀は適用致しません	FW-U1P201, 301 (Ai), 303Ai, 501 (Ai), 503 (Ai/AiX), 505Ai, 555S II, 603AiX, 605 (Ai/AiX), 607, 609, 611, 633L, 701, FW-U1V703F2 (X) リボン品番: CF-PR230K, PR231K, PR232K, PR251K ※金, 銀は適用致しません	SWP-340 (H), 360, 380, 700, 1450, M50, M60, M70, M71, M75, M80, M81, M85, M100, NS4B, NS5, NS6, NS7, NS10, S50, ER500, ER600, ER700, ER980 リボン品番: SWP-RIX (K), RIX (K), RI (K), MWP-501SB	BP-1, BW-170, 180 (D/S), 190, 220, 230, 300, TF-200, 250 (GM), 400 リボン品番: PT-CR/DB-2 (BC)	JP-90LX, N-10, 11, 12, 21Ai, NL-1, P-1, 1100, 1300, 2200, 2300, 2400, 2500, 3200 リボン品番: TPリボンR-1, R-2, R-3
RW302ACL マルチカラー (はがき縦幅専用)		WD-J150, J200, CP1, CP2, MA-10 リボン品番: RW302ACL				CX-1, 11, 20, HX-1, 3, 5, 6, 7, 8, 10, HV-100, 120, 150, 500, 550, 200L, 250L, 260L, 270L, 280L, 290L, 700L, GX-40, 50 リボン品番: T-W-CH, NR-30CR		SWP-ER500, ER600, ER700, S50, AL10, ER980 リボン品番: SWP-RIXC		
RW303ACL マルチカラー (A4用)		WD-CP1, CP2, MA-10 リボン品番: RW303ACL								

ワープロ用リボンカセット 適用機種一覧表

共通リボンカセット/タイプEW

メーカー	シャープ	NEC	富士通	東芝	カシオ	松下	三洋	日立	リコー
リボン品番 MR-1 WD-C10, C20, C50, G200, M500, M600, M700, M710, M800, 880EX, M900, 990EX, VP1, EX1, VP2, EX2, VP3 (黒) リボン品番: RW201ABK	5UC, 5UH, 5UV, 5ZC, 5ZH, 5ZV, JX-30SA, 35SA, 50MA, 55MA, 70MA, 5300 (AC/AS), 5500 (AC/AS/BC/BS), 5700AC, S300, S500, S510, S700, A200, A300, A500, 720, 730, 750 リボン品番: PWP-IR71, IR-EW-B	30LX701, mariott (Plus), LX-1000, 2000, 2100 (J/S), 3000, 3100 (J/S), 3100C (J/S), 3300C (J/S), 3500 (GT/NT), 4300, 4500 (NT), 6000, 6500 (SD) B10, B110, B150, C300, 7500 (SD/DS/DJ), 9000, 9500SD, C500, B250, S5000, C700 リボン品番: 0315210	JW-06H, 06P, 98A, 98 (GT/GX), F300, F510, F550, F580, V600, V610, V700, V810, V850, V855, V860, V865, V880, V900, V980, C660, 4020, 6020, 8020, 8120, 9820, 98BW (Ⅱ, Ⅲ), 6120, G7000 リボン品番: JW-Z407	G-98, 99 (AX/HX), HW-98G, GX-990, 500, 1000, 8000, 700, G-700, 770ZT, 800ST, 880ST, 900ST, 990, CX-70, 100, 300, 5000, 6000, 7000, 8000, 9000, 6500, 6800 リボン品番: T-EW-BK ※単色カラーは適用致しません	FW-U1P93, U1P95, U1P97F, U1P98 (F/FE), U1C30, U1C33, U1C70, U1C71, U1C80, U1C83, U1C89 リボン品番: CF-PR280K ※金, 銀は適用致しません	SWP-NS15, NS20 (HL), NS25, NS30F, NS35, NS40, S50C, V400 (C), V450C, V500 (C/GI/GL), V550 (C/GI), M55 (H), M57 (S), S60C リボン品番: SWP-HR (K) ※金, 銀は適用致しません	BF-200 リボン品番: PT-CR/DB-3 (BC) ※単色カラーは適用致しません	NT-500, 510 リボン品番: TPリボンT-1 ※単色カラーは適用致しません	
MR-1 WD-C10, C20, C50, G200, M500, M600, M700, M710, M800, 880EX, M900, 990EX, VP1, EX1, VP2, EX2, VP3 マルチカラー (はがき縦幅専用) リボン品番: RW202ACL	5UC, 5UH, 5UV, 5ZC, 5ZH, 5ZV, JX-30SA, 35SA, 50MA, 55MA, 70MA, 5300 (AC/AS), 5500 (AC/AS/BC/BS), 5700AC, S300, S500, S510, S700, A200, A300, A500, 750 但し、5UC, 5UH, 5UVに使用する 場合は、専用FDが必要です。 リボン品番: IR-EW-XHA	mariott (Plus), LX-1000, 2000, 2100 (J/S), 3000, 3100 (J/S), 3100C (J/S), 3300C (J/S), 3500 (GT/NT), 4300, 4500 (NT), 6000, 6500 (SD) B10, B110, B150, C300, 7500 (SD/DS/DJ), 9000, 9500SD, C500, B250, S5000, C700 リボン品番: 0315280	JW-06H, 06P, 98A, 98 (GT/GX), F300, F510, F550, F580, V600, V610, V700, V810, V850, V855, V860, V865, V880, V900, V980, C660, 4020, 6020, 8020, 8120, 9820, 98BW (Ⅱ, Ⅲ), 6120, G7000 リボン品番: JW-Z430	G-98, 99 (AX/HX), HW-98G, GX-990, 500, 1000, 8000, 700, G-700, 770ZT, 800ST, 880ST, 900ST, 990, CX-70, 100, 300, 5000, 6000, 7000, 8000, 9000 リボン品番: T-EW-CH	FW-U1P98 (F/FE), U1C30, U1C33, U1C70, U1C71, U1C80, U1C83, U1C89 リボン品番: CF-PR280MH	SWP-V400 (C), V450C, V500 (C/GI/GL), V550 (C/GI), S50C, M57 (S), S60C リボン品番: SWP-HRC1			
MR-1 WD-C10, C20, C50, G200, M500, M600, M700, M710, M800, 880EX, M900, 990EX, VP1, EX1, VP2, EX2, VP3 マルチカラー (A4用) リボン品番: RW203ACL	5UC, 5UH, 5UV, 5ZC, 5ZH, 5ZV, JX-35SA, 50MA, 55MA, 70MA, 5300 (AC/AS), 5500 (AC/AS/BC/BS), 5700AC, S300, S500, S510, S700, A200, A300, A500, 750 但し、5UC, 5UH, 5UVに使用する 場合は、専用FDが必要です。 リボン品番: IR-EW-XA	mariott (Plus), LX-1000, 2000, 2100 (J/S), 3000, 3100 (J/S), 3100C (J/S), 3300C (J/S), 3500 (GT/NT), 4300, 4500 (NT), 6000, 6500 (SD) B10, B110, B150, C300, 7500 (SD/DS/DJ), 9000, 9500SD, C500, B250, S5000, C700 リボン品番: 0315270	JW-06H, 06P, 98A, 98 (GT/GX), F300, F510, F550, F580, V600, V610, V700, V810, V850, V855, V860, V865, V880, V900, V980, C660, 6020, 8020, 8120, 9820, 98BW (Ⅱ, Ⅲ), 6120, G7000 リボン品番: JW-Z431	G-99 (AX/HX), HW-98G, GX-990, 500, 1000, 8000, 700, G-700, 770ZT, 800ST, 880ST, 900ST, 990, CX-70, 100, 300, 5000, 6000, 7000, 8000 リボン品番: T-EW-CA	FW-U1C30, U1C33, U1C70, U1C71, U1C80, U1C83, U1C89 リボン品番: CF-PR280M3	SWP-V400 (C), V450C, V500 (C/GI/GL), V550 (C/GI), S50C, S60C リボン品番: SWP-HRC2			
MR-1 WD-M600, M700, M710, M800, 880EX, M900, 990EX, VP1, EX1, VP2, EX2, VP3 (フォトプリント用) ※…1 リボン品番: RW214ACL	JX-35SA, S300, S500, S510, S700, A300, A500, 750 リボン品番: FR-EW-XH	mariott (Plus), LX-4500 (NT), 6000, 6500 (SD) 7500 (SD/DS/DJ), 9000, 9500SD, S5000 リボン品番: 0315290	JW-V850, V855, V860, V865, V880, V980, 8020, 8120, 9820, 98BW (Ⅱ, Ⅲ) リボン品番: JW-Z530	GX-5000, 6000, 7000, 8000, 9000, GX-500, 1000, 700 リボン品番: T-EW-PH	FW-U1C83 リボン品番: CF-280MH				
WD-M800, 880EX, M900, 990EX, VP1, EX1, VP2, EX2, VP3 (官製はがきフォト用) リボン品番: RW215ACL	JX-S300, S500, S510, S700, A300, A500, 750 リボン品番: FR-EW-XP	LX-6000, 6500 (SD), 7500 (SD/DS/DJ), 9000, 9500SD, S5000 リボン品番: 0315610	JW-V860, V865, V880, V980, 8020, 8120, 9820, 98BW (Ⅱ, Ⅲ) リボン品番: JW-Z540	CX-6000, 8000, 9000, GX-500, 1000, 700 リボン品番: T-EW-PP	FW-U1C83 リボン品番: CF-280PP				
WD-VP1, EX1, VP2, EX2, VP3 ハイグレードリボン (はがき縦幅専用) リボン品番: RW206ACL	JX-A200, A300, A500, 720, 730, 750 リボン品番: IR-EW-HGH	LX-9000, 9500SD, S5000 リボン品番: 0315630	JW-8020, 8120, 9820, 98BWⅢ, 6120 リボン品番: JW-Z440	CX-9000, GX-500, 1000, 700 リボン品番: T-EW-FH					
WD-VP1, EX1, VP2, EX2, VP3 ハイグレードリボン (A4用) リボン品番: RW207ACL	JX-A200, A300, A500, 720, 730, 750 リボン品番: IR-EW-HGA	LX-9000, 9500SD, S5000 リボン品番: 0315620	JW-8020, 9820, 8120, 98BWⅢ, 6120 リボン品番: JW-Z441	CX-9000, GX-500, 1000, 700 リボン品番: T-EW-FA					

※…1 当リボンはフォトプリント専用紙と合わせてご使用下さい。